

TCPP Mask Node

How to run the mask node beside a TCPP node and read what it shows: the masks a node delivers, the values that fill them, and the error code it answers every request with. Everything it shares with the node is in the [node's manual](#).

Three requests

`mask_output`,
`display_output` and
`ping`; anything else is
answered with an error.

Auto-reply

Every request gets a signed
response whose
`error_code` says what was
found.

One binary

The node's code with a
display on top. Nothing to
install.

CONTENTS

- | | |
|---|--------------------------------|
| 01 What a mask node is | 06 The library across restarts |
| 02 Getting started | 07 Workflows |
| 03 The Mask view | 08 Command line |
| 04 Answers and the two switches | 09 HTTP API |
| 05 What it accepts, and what it answers | 10 Appendix |

■ What a mask node is

`tcpp-mask` is a second executable, built from the same code as the node: a TCPP module that behaves like a display. A node delivers a layout to it with `mask_output` and fills that layout with `display_output`; the mask node draws the result as a device screen and answers every request on its own, with a signed response whose `error_code` says what it found. That gives a node, or a TCPP implementation of your own, a counterpart to talk to that checks what it is sent the way a display would.

Everything else about it is the node: the same identity, frame log, peers and signatures, and the same `Compose`, `Inbox`, `Sent`, `Peers`, `Identity` and `Log` views, kept as debug tabs below its own `Mask` view. The [node's manual](#) describes those, and what it says applies here unchanged. This manual covers what the mask node adds.

■ Getting started

What you were given

One executable, downloaded as an archive of its own beside the node's, `tcp-mask-...-windows-amd64.zip`. Like the node it needs nothing installed and reaches out to nothing on the internet. Unpack it and start it from a terminal:

```
# Windows
.\tcp-mask.exe

# macOS and Linux
chmod +x tcp-mask
./tcp-mask
```

The download is unsigned, so the first start meets the same warnings as the node's; [Getting started](#) in the node's manual says how to get past each.

Running it beside a node

A mask node is no use alone: it waits for a node to send it masks. Its defaults are chosen so that it pairs with a node started on the usual port:

SETTING	NODE	MASK NODE
<code>--port</code>	8443	8444
<code>--peer</code>	itself	localhost:8443
<code>--node-type</code>	CSU	LDU, the local display unit the mask examples address
its files	in <code>tcp-node-data/</code> beside the binary	in <code>tcp-mask-data/</code> beside the binary

```
# PowerShell, two windows
.\tcpp-node.exe --peer localhost:8444
.\tcpp-mask.exe

# macOS and Linux
./tcpp-node --peer localhost:8444
./tcpp-mask
```

Open `https://localhost:8443/` for the node and `https://localhost:8444/` for the mask node. Each has its own self-signed certificate, so the browser warns once for each.

What appears on disk

Each keeps its key, certificate, log and records in a folder of its own, `tcpp-node-data/` or `tcpp-mask-data/`, so the mask node can be unpacked into the same directory as a node without the two sharing an identity. The files in `tcpp-mask-data/` are the node's, listed under [What appears on disk](#). On startup it prints the node's banner and three lines of its own:

```
2026/10/22 11:39:51 TCPP mask node LDU / P:NODE-01D1F0C8
2026/10/22 11:39:51   listening   https://localhost:8445/
2026/10/22 11:39:51   identity   C:\Users\User\tcpp-lab\m\tcpp-mask-data
...
2026/10/22 11:39:51   masks      0 in the library
2026/10/22 11:39:51   accepts   mask_output, display_output, ping
2026/10/22 11:39:51   auto-reply on, strict checks on
```

The lab used in this manual

The figures come from the node manual's [two-node lab](#) and a third instance beside it, **M**, started with `--port 8445` because node **B** already holds 8444. Node **A** sent it the meter sample's `mask_output`, then its `display_output`, then a `display_output` naming a mask **M** was never given, and a `ping`.

■ The Mask view

TCP Mask Node schema 1.3.0 | LDU / P: NODE-01D1F0C8 | :8445 | ES384 · 01d1f0c8 | LIVE

MASKS

Mask

DEBUG

Compose

Inbox 4

Sent

Peers

Identity

Log

MASK.METER.AC.L004C030
30x6 received 11:40:17 values

Every mask output this node accepted; it starts empty. Pick one to show it; a frame that arrives switches to its mask.

MASK.METER.AC.L004C030
I: MASK.METER.AC.L004C030.1.0.0 · 30 chars × 4 lines · received in frame f-20261022T094017-001-9f22

Region: de-DE ☒ Field outlines and ruler

Values from display_output frame f-20261022T094017-003-7648 at 11:40:17.

Press a button or Enter in an input field on the screen to see the display_input it stands for.

FIELDS

FIELD_ID	FIELD_SIGN	FIELD_TYPE	LINE	CHAR	LENGTH	VALUE	MANDATORY	NOHID
I:1010	GENERAL.DATETIME	OUTPUT.DATETIME	1	1	20	21.09.2026 14:15:00	yes	
I:1011	GENERAL.DATETIME	OUTPUT.TEXT	1	22	6	0 h		
I:1020	METER.ACTUAL.KWH	OUTPUT.NUMERIC	2	1	20	2032.8	yes	
I:1021	METER.ACTUAL.KWH	OUTPUT.TEXT	2	22	6	kWh		
I:1030	METER.ACTUAL.TARIFF.ID	OUTPUT.STRING	3	1	20	HT	yes	
I:1031	METER.ACTUAL.TARIFF	OUTPUT.TEXT	3	22	6	Tarif		
I:1040	METER.ID	OUTPUT.STRING	4	1	20	1ESY1170046711	yes	
I:1041	METER.ID	OUTPUT.TEXT	4	22	3	ID		
I:1042	METER.ACTUAL.STATUS	OUTPUT.LIGHT	4	27	1	OK		

ANSWERS

☒ **Auto-reply**
answer every request with its error code

☒ **Strict checks**
reject masks off the grid or overlapping, and values for unknown fields

ping REQUEST [000000] 11:40:17
from CSU-node answered - 202 accepted

display_output REQUEST [3FFFFFFF] 11:40:17
from CSU-node answered - 202 accepted
display_mask_id I: MASK.METER.AC.L004C030.1.0.0
names no mask this node has; send its mask_output first

display_output REQUEST [000000] 11:40:17
from CSU-node answered - 202 accepted

mask_output REQUEST [000000] 11:40:17
from CSU-node answered - 202 accepted

frames 8

FIGURE 01 · The mask node opens on **Mask**. The node's own views sit below it under *Debug*.

- **Masks**, on the left, is the library: every mask the node accepted, each with its size in characters × lines, where it came from, its layout issues and whether values have arrived for it. Click one to show it. A frame that arrives for a mask switches the view to that mask.
- The middle column is the mask itself: its sign, id, size and the frame it came in, the device screen, the frame its values came from, and the **Fields** table, one row per field with its id, sign, type, position, length, current value and flags.
- **Answers**, on the right, lists every request the node received with the code it was answered with.

The screen




FIGURE 02 • The screen with `Field outlines and ruler` on.

The screen is drawn on the mask's character grid. `Region` picks which of the mask's regions (such as `de-DE`) the labels are shown in. `Field outlines and ruler` frames each field and numbers the lines and every tenth column, which is the quickest way to see a field that is off by one. Pressing a button or Enter in an input field on the screen prints the `display_input` that press stands for, below the screen; the mask node does not send it.

■ Answers and the two switches

ANSWERS		
☒ Auto-reply	answer every request with its error code	
☒ Strict checks	reject masks off the grid or overlapping, and values for unknown fields	
ping REQUEST	000000	11:40:17
from CSU-node answered · 202 accepted		
display_output REQUEST	3FFFFFF	11:40:17
from CSU-node answered · 202 accepted		
display_mask_id I:MASK.METER.DC.L004C030.1.0.0		
names no mask this node has; send its		
mask_output first		
display_output REQUEST	000000	11:40:17
from CSU-node answered · 202 accepted		
mask_output REQUEST	000000	11:40:17
from CSU-node answered · 202 accepted		

FIGURE 03 · Four requests from node A, each answered on its own. The 3FFFFFF one named a mask the node never received.

Each line names the request, the code it was answered with, the peer, and whether the answer was delivered. A code other than 000000 comes with the reason, which is also what the answer carries in error_text .

SWITCH	FLAG	OFF MEANS
Auto-reply	--auto-reply	Answers are still worked out and listed, but nothing is sent: the frame waits in Inbox for a reply made by hand, as on a node.
Strict checks	--strict-layout	A mask with layout findings, and values for fields the mask does not have, are accepted, and the findings are shown instead of answered.

Both are on by default. The flags set them at startup, for example --strict-layout=false ; the switches change them while the node runs.

■ What it accepts, and what it answers

- `mask_output` delivers a layout. Accepted, it joins the library, replacing one with the same `mask_id`, and is shown.
- `display_output` fills a mask with values. The mask is named by `display_mask_id`, and each value is bound to its field by `field_id`.
- `ping` is answered with the `ping_response` example's record.

Any other request is answered with an error. Responses are never answered, so two answering nodes cannot loop. The codes come from `all_error_codes`, with `FFF` as the module digits, as in the specification's own examples:

FOUND	ERROR_CODE
frame is not a JWS / payload not JSON / no head	<code>103FFF</code> / <code>201FFF</code> / <code>202FFF</code> , shown but not answered: there is no head to answer
signature does not match the stored peer key	<code>104FFF</code>
a head member fails its schema	<code>211</code> – <code>232</code> by member (<code>213FFF</code> <code>record_u dt</code> , <code>222FFF</code> <code>origin_id</code> , ...), else <code>203FFF</code>
<code>record_type</code> not one of the three	<code>211FFF</code>
<code>record_direction</code> other than request	<code>212FFF</code>
record missing or empty	<code>301FFF</code>
required element missing / required value null / wrong type, pattern, length	<code>302FFF</code> / <code>303FFF</code> / <code>4FFFFF</code>
mask off the grid, overlapping, or reusing a <code>field_id</code> (strict)	<code>303FFF</code>
<code>display_mask_id</code> names no known mask, or a value names no field of it (strict)	<code>3FFFFF</code>
none of the above	<code>000000</code>

`parsed` carries the code at the path of each finding, for example `record/mask/mask_fields/14`, and up through `record/mask` and `record`. `error_text` says what was wrong, cut to the characters the head's pattern allows.

A head member that failed its own check is not echoed back: the node's own type and id, or the sender's `X-TCPP-Node`, stand in for it.

■ The library across restarts

The library follows the frame log, as the inbox does. It starts empty — masks only arrive from a peer, the shipped examples are for the node that sends them — and on startup the received frames are replayed oldest first. Where the log holds the answer that went out, that answer counts: a mask accepted with strict checks off stays accepted after a restart with them on.

To start over with an empty library, stop the mask node and remove `tcpp-frames.jsonl` from `tcpp-mask-data/`. Its key and its peers stay, so it is still the same node to everyone who verifies it.

■ Workflows

A. Drive a mask from a node

- 01 Start a node with `--peer localhost:8444` and the mask node beside it, and open both in the browser.
- 02 On the node, open **Compose**, select `mask_output`, press **Load...** → `example_meter` and **Sign & Send**. The mask node shows the meter mask, with no values yet.
- 03 Select `display_output`, load `example_meter` and send it. The screen fills with the meter's values.
- 04 Both answers arrive in the node's **Inbox** as responses tied to their requests, and the mask node lists them under **Answers**.
- 05 Change a `field_id` or the `display_mask_id` and send again to see the code a display answers a faulty frame with.

AN OLDER NODE HOLDS OLDER SAMPLES

The `mask_output` and `display_output` samples were revised after the build of 21 October 2026, so that each `display_output` fills the mask of the same variant. A node directory created with that build or an earlier one keeps its `records/mask_output_request/` and `records/display_output_request/` as they were, because an existing schema directory is never re-seeded: delete both from `tcpp-node-data/` and restart the node to have the current samples written.

B. Answer a frame by hand

- 01 Switch **Auto-reply** off, or start the mask node with `--auto-reply=false`.
- 02 Send it a request from the node. It still shows the mask and lists the code it would have answered with, but sends nothing.

03 Open the debug tab [Inbox](#) on the mask node and select the frame: the reply form is the node's, pre-filled from the request.

04 Set `error_code` and `parsed` to whatever your test needs, and press [Sign & Send response](#) .

■ Command line

The mask node takes every flag of the node, described under [Command line and files](#) in its manual. Four of them start from other defaults, and two are its own:

FLAG	DEFAULT	MEANING
<code>--port</code>	<code>8444</code>	TLS port to listen on.
<code>--peer</code>	<code>localhost:8443</code>	Default target, and where a node on the usual port listens.
<code>--node-type</code>	<code>LDU</code> , or the stored value	Three uppercase letters. Persisted after the first run.
<code>--data-dir</code>	<code>tcpp-mask-data/</code> beside the binary	Where the key, certificate, log, peers and records live.
<code>--auto-reply</code>	<code>true</code>	Answer received requests without the operator. Switchable in the browser.
<code>--strict-layout</code>	<code>true</code>	Reject masks that do not lay out cleanly, and values for unknown fields. Switchable in the browser.

The data folder is not called `tcpp-mask/` because on macOS and Linux that is the binary's own name. It runs and stops like the node; a failed start prints `tcppmask: <reason>` and exits `1`.

■ HTTP API

The mask node serves every route of the node, listed under [HTTP API](#) in its manual, with the same absence of authentication. The mask view uses three more:

ROUTE	MEANING
GET /api/mask/state	The library, the mask shown, its values and layout findings, the answers given and the two settings.
POST /api/mask/active	Show another mask: {"mask_id":"..."} . 404 when the library has no such mask.
PUT /api/mask/settings	Change either switch: {"auto_reply":true,"strict":false}; a member left out keeps its value. Returns both settings.

```
# turn strict checks off on a running mask node
curl -k -X PUT https://localhost:8444/api/mask/settings \
  -H 'content-type: application/json' -d '{"strict":false}'
```

■ Appendix

Glossary

Mask

A screen layout delivered with `mask_output`: a grid of characters × lines and the fields placed on it, named by its `mask_id`.

Field

One place on a mask, named by its `field_id`, that a `display_output` value is written into.

Region

A language variant of a mask's labels, such as `de-DE`.

Mask node

`tcpp-mask`, a node that shows masks and answers every request with an error code, as a display would.

Frame, peer, record

As in the [node's manual](#).

About the figures

Every screenshot in this manual was taken from a running mask node beside the node manual's two-node lab, not drawn, so what you see here is what the application does. They are captured by the same script as the node's figures, which drives a headless browser through the steps an operator takes, and they are retaken whenever the interface changes.

`tcpp.digital` English mask node manual · schema 1.3.0

Figures captured from a mask node (LDU on 8445) beside a two-node lab on 22 October 2026. Parts of these documents have been authored with AI assistance.